

## CAR BODY TESTER MG-101

- It is a pocket-size tester which enables checking the condition of car body and determining the thickness of the varnish (lacquer) layer.
- Good quality and accuracy for a reasonable price.
- Enables to check whether the car has been painted for the second time or the body has been repaired after crash.
- Makes possible to find where the filler has been laid and how thick it is.
- It is possible to check whether the car has been well-repaired or the rough places were just filled.
- 6-level scale enables estimating the thickness of measured layer more accurately than with use of other testers.
- The tester is ready to work without any preparation.
- Waterproof housing enables work even during rain.
- Automatic switch off function protects the batteries against discharging.
- The user's manual includes the data about typical varnish thickness on cars and information about the way of evaluating the quality of repairs.
- Warranty 24 months.



Ranges ( $\mu\text{m}$ )	Parameters
0 ÷ 150	
150 ÷ 200	Accuracy 5%
200 ÷ 350	Length 145mm
350 ÷ 500	Diameter $\phi$ 26 mm
500 ÷ 1000	Weight 55 g
1000 ÷ 1200	Power supply: 3 x LR44 batteries
above 1200	

**ELMEIRON® Sp. j.**

41-814 Zabrze. Witosa 10 POLAND

tel. +48 32 2738106

[www.elmetron.pl](http://www.elmetron.pl) e-mail: [info@elmetron.com.pl](mailto:info@elmetron.com.pl)